

USER GUIDE

DROPPING OFF OR PICKING UP CYLINDERS FROM CUSTOMER SITES



Your Cylinder Tracking, Reporting and Stock Management Solution.





DROPPING OFF OR PICKING UP CYLINDERS FROM CUSTOMERS SITES

Note: Engineers can also drop off or pickup cylinders from a company cylinder store location

To drop off a cylinder at a customer site

1. Click on Cylinder Stock




2. Click on the relevant cylinder




3. Click Transfer






4. Select the Customer




5. Select the **Site** your leaving it at by using the looking up glass in the right hand corner and type in the site name or scroll through the sites.





6. Click **Ok** to confirm






To pick up a cylinder from a customer site (or cylinder store)

1. Click on Cylinder Stock Icon



2. Click on the cylinder you want to pick up from site by scrolling through the cylinders or use the magnifying glass in the top right-hand corner if you know the serial number.





3. Click Pick up

